

Technical Specifications

Power supply	9 ... 28VDC
Power consumption	typ. 0.35W
Power loss	max. 0.16W
Interfaces	Loxone Tree: connection with Miniserver / Tree Extension
Ambient temperature	-20 ... 55°C / -4 ... 131°F
Humidity	max. 95% r.H. (non condensing)
Temperature detection range	-40 ... 120°C / -40 ... 248°F, ± 0.5°C / 0.9°F
Humidity detection range	0 ... 100% r.H. +/- 2% (non condensing)
CO2 detection range	400 ... 10.000ppm, ±(30 ppm + 3%)
Safety rating	IP20
Dimensions	80x80x18mm / 3.15x3.15x0.71" (LxWxH)
Maintenance & Cleaning	This device is free of main- tenance and may only be cleaned with a dry cloth.

LOXONE

**Loxone
Electronics GmbH**
Smart Home 1
4154 Kollerschlag
Austria

Loxone UK
The Forum
Station Road
Theale, RG7 4RA
United Kingdom



For additional information,
declaration of conformity, visit
www.loxone.com/datasheets

V020425

Need Help?
loxone.com/support



LOXONE



Room Comfort Sensor Tree

Part No: 100276 (White)
Part No: 100277 (Anthracite)

About the product

The Room Comfort Sensor Tree ensures rooms are always comfortable, by measuring temperature, humidity, and air quality using a CO2 sensor. Together with the Miniserver, this information can be used to control, monitor and record statistics for the temperature and air quality in a room.

Features

- Temperature sensor
- Humidity sensor
- CO2 sensor

Installation

Fix the mounting plate to your installation box. Now connect power and Tree communication to the Room Comfort Sensor Tree through the frame. Place the Room Comfort Sensor including the frame on top of the mounting plate and gently push to clip into place.

This folder is a part of the product!



For additional information,
visit www.loxone.com/help/room-comfort-sensor-tree

Connection

Wire cross-section	0.25 ... 0.8mm ² / AWG18 ... 23
Stripping length	5mm / 0.2"
Temperature resistance	-40 ... 105°C / -40 ... 221°F
Orange / White	+ 24VDC / GND
Green / White	Loxone Tree

